

READ INSTRUCTIONS CAREFULLY BEFORE STARTING THE PROJECT. REMEMBER THAT SAFETY COMES FIRST. OUR CHIMNEY SYSTEMS ARE DESIGNED FOR INSTALLATION BY A QUALIFIED PERSON IN ACCORDANCE WITH LOCAL BUILDING CODES.

CAUTION: WEAR CUT RESISTANT GLOVES WHILE HANDLING METAL PARTS TO AVOID PERSONAL INJURY. SHARP EDGES OR PROJECTIONS CAN CUT YOU.



LISTED A218

Tested to: UL 103 HT, ULC-S629

ROUND TOP (RT/SRT)

1. Place the Round Top over an installed chimney Length so that the three legs slide down over the outside of the chimney (see Figure 1).
2. Press down evenly on the lower skirt so that the skirt seats tightly on the upper edge of the chimney Length (see Figure 2).
3. Be sure the Round Top is level. Place the Cinch Band over the Length and all legs so that the Cinch Band rests evenly on the turned-out flanges (see Figure 3).
4. Firmly tighten the Cinch Band with screw and nut provided (Figure 4). To remove the Round Top, simply loosen the Cinch Band and slide Round Top off the Length.



FIGURE 1



FIGURE 2



FIGURE 3




FIGURE 4