



CAUTION: WEAR GLOVES WHILE HANDLING METAL PARTS TO AVOID PERSONAL INJURY. SHARP EDGES OR PROJECTIONS CAN CUT YOU.


Selkirk Chimney Systems (USA Only - See separate instructions for Canada)

SUPPLEMENT TO SHEET S-3

INSTALLATION INSTRUCTION SUPPLEMENT FOR “EZ-CT” ROUND TOP

Model “EZ-CT” Round Top is a smaller profile version of the “CT” Round Top termination / raincap, incorporating no windband or lower “skirt”

NOTE: THE “EZ-CT” CAP PROVIDES LESS RAIN PROTECTION AND WIND RESISTANCE THAN THE STANDARD “CT” TOP. IT IS NOT RECOMMENDED FOR USE DIRECTLY ABOVE THE OUTLET OF AN APPLIANCE IF WIND-DRIVEN RAINWATER COULD ENTER AND DAMAGE THE APPLIANCE. THIS CAP IS MOST SUITABLE FOR INSTALLATIONS IN WHICH A “DRIP TEE” OR FIREPLACE “SMOKE SHELF” INTERCEPTS ANY WIND-DRIVEN RAIN ENTERING THE CHIMNEY.

 WARNING
Failure to follow the instructions could cause FIRE, CARBON MONOXIDE POISONING, OR DEATH. If you are unsure of installation requirements, call the Phone Number listed on the instructions or sizing handbook or visit www.selkirkcorp.com .

Read and follow important clearance and safety precautions described in Sheet GS before installing this cap. Sheet GS is the Selkirk Chimney System (SCS) general installation instruction sheet provided with Roof, Wall, Ceiling, and Anchor Plate Support Assembly packages.

TO INSTALL:

1. Place EZ-CT down over the top section of the chimney. Bottom of EZ-CT incorporates non-lanced female coupler which seats directly over outlet of chimney, but does not tighten by twisting.
2. Place locking band around joint, overlapping the rolled edges of the adjacent couplers. Secure tightly with nut / screw provided.
3. Tighten until cap is secure and cannot be rotated or lifted.

